



	TYPE:	FRENCH DOOR
	OPERATION:	OUTSWING FRENCH DOOR
	SILL ADAPTER:	#5 SQUARE ADAPTER (TOP)